## Etna & Havana

## Service Document – Failure Codes & Display Description

W10758657

Rev.: C / EN 785792 17.02.15

|                             |                             | Water Temperature Sensor Error   |  |
|-----------------------------|-----------------------------|--|--|
| U1                          |                             | If the water temperature sensor (NTC) value is out of range, the program runs without heating. If the NTC value is in range, but there is not at least a change in NTC value of +2°C during heating or -2°C in case of re-fills during heating detected, the program continues without additional heating.           |  |
| (2)                         |                             | Potential Causes   |  |
| U2 / U3                     | F05                         | Check the NTC resistance     Check connections to the NTC and CUC  |  |
| $\triangle$                 |                             | This failure is handled as delayed failure. Only at the 10 <sup>th</sup> occurance the customer is notified.   |  |
|                             |                             | During the time until the failure is declared there might be calls like: "poor wash performance / does not heating".   |  |
|                             |                             | Reprogram CUC in case of F05 otherwise the failure will remain.  |  |
|                             |                             | Blocked drum / Overload of motor   |  |
| Only during<br>Service Test |                             | The control unit is not able to move the motor or it is very hard to move the motor. There are many re-trials to run the motor. The program continues and finishes without motor movement or with reduced motor movement.  |  |
| <b>U1</b>                   | Only during<br>Service Test | This failure is handled as hidden failure. The customer is not notified.  This will lead to calls "drum not moving / drum not properly moving / poor wash performance / poor rinse performance / no spinning / laundry very wet".  |  |
|                             | F06                         | Potential Causes   |  |
| U2 / U3                     | 100                         | Check wire harness and connections between the Motor and CUC  Check drum for blockage (make the check slowly and only for short time, the drum will be braked, if you rotate the drum for several seconds and / or if you do it fast) instruct customer for trapped laundry  Check resistances of the Motor windings |  |

Check if the correct motor is mounted

mounted

In case of Direct Drive Motor: Check if the correct combination of stator and rotor is